

Air Conditioning

Ensure all external doors and windows are closed when using the air conditioning as this ensures that it works effectively and efficiently.

The apartment contains 2 air conditioning units as follows:


Air Conditioning Unit Location	Remote Control Location
Lounge/Dining	Stored in remote caddy next to TV
Master bedroom	Wall mounted in the master bedroom near the entry door

An overview of the remote control is shown below. The complete user manual is available on the Detailed User Manuals page.

The primary buttons of interest are:

- On/Off
- TEMP - Changing the temperature
- Mode - Leave this set to Auto - for selecting heating/cooling

Signal transmitter



- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is approx. 7m.

FAN setting button

- It selects the airflow rate setting.

▶ Page 14

POWERFUL button

- POWERFUL operation. ▶ Page 17

Display (LCD)

- It displays the current settings. (In this illustration, each section is shown with all its displays on for the purpose of explanation.)

TEMPERATURE adjustment buttons

- It changes the temperature setting.

▶ Page 12


ON/OFF button

- Press this button once to start operation.

Press once again to stop it. ▶ Page 11

Front cover

- Open the front cover. ▶ Page 8





MODE selector button

- It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN) ▶Page 11

ECONO button

- ECONO operation. ▶Page 19

QUIET button

- OUTDOOR UNIT QUIET operation. ▶Page 18

SWING button

- Adjusting the airflow direction. ▶Page 13

COMFORT/SENSOR button

- COMFORT AIRFLOW and INTELLIGENT EYE operation. ▶Page 15,16

OFF TIMER button

▶Page 20

TIMER CANCEL button

- It cancels the timer setting. ▶Page 20,21
- It cannot be used for the WEEKLY TIMER operation.

WEEKLY : WEEKLY button

↔ : PROGRAM button

COPY : COPY button

BACK : BACK button

NEXT : NEXT button

- WEEKLY TIMER operation. ▶Page 22

ON TIMER button

▶Page 21

CLOCK button

▶Page 10

SELECT button

- It changes the ON/OFF TIMER and WEEKLY TIMER settings. ▶Page 20,21,22

