

# Home Theatre System

## Pairing a Bluetooth Device

Follow the 6 steps shown below to pair your bluetooth-capable device to the Home Theatre System

## BLUETOOTH Function

# Using the BLUETOOTH function

### Pairing automatically

If the system is not paired with any equipment, you must pair the system with the equipment to be connected. Select "BT AU" with the INPUT button on the remote control to enter pairing mode.

- 1 Place the system and a BLUETOOTH device within 1 meter (3.3 feet).**
- 2 Press INPUT to select "BT AU."**
- 3 Set the BLUETOOTH device in pairing mode.**

For details on setting the BLUETOOTH device in pairing mode, refer to the operating instructions supplied with the device.
- 4 When the detected devices are listed on the BLUETOOTH device, check that "HT-CT660" is listed.**

On some BLUETOOTH devices, the list may not be displayed.
- 5 Select "HT-CT660" on the list.**

If entering a Passkey is requested, enter "0000."

## 6 Make the BLUETOOTH connection on the BLUETOOTH device.

When the BLUETOOTH connection is made correctly, the illumination LED lights up in blue and the pairing information is stored in the system.

### About the LED for BLUETOOTH

The illumination LED lights up or flashes in blue to indicate the BLUETOOTH status.

System status	LED status
During BLUETOOTH pairing	Flashes quickly in blue.
The system is attempting to connect with a BLUETOOTH device	Flashes in blue.
The system has established in connection with a BLUETOOTH device	Lights up in blue.
The system is in BLUETOOTH standby mode (when the system is off)	Flashes slowly in blue.

#### Notes

- For details on operation of the connected devices, refer to the operating instructions supplied with the devices.
- The BLUETOOTH devices to be connected must support A2DP (Advanced Audio Distribution Profile).
- Use a BLUETOOTH device such as BLUETOOTH mobile phone in an easily visible place in the same room where the Sound Bar is placed.
- If Wi-Fi equipment is used, BLUETOOTH communication may become unstable. In that case, use the BLUETOOTH device as close as possible to the Sound Bar.
- Sound may be interrupted because of a problem with the BLUETOOTH device.