

Washing Machine

Video

Steps

- Open the Laundry cupboard door
- Using the dial, select the wash programme
- Open the door
- Put clothes in
- Close door
- Open Powder drawer
- Put Laundry powder in the left slot
- Close the powder drawer
- Press the start button
- At the end of the wash cycle the machine will beep
- Open door
- Remove clothes
- Close door
- Turn machine off by using the dial